


Instruction Sheet For Tool No.1279



Inner Cam Bearing Puller Use on all Twin Cam 88™ Models Designed like our popular EVO cam bearing tool, it removes the bearing easily without any damage to the crankcase. This precision built tool will also keep the pin rollers from accidentally falling into the crankcase.

PARTS AVAILABLE SEPARATELY			
No.	Qty.	Description	Part No.
1	1	Dowel Pin	95760-TB-1
2.	1	3/4" Brass Washer	1099
3.	1	Nut	1098
4.	1	Remover Body	1279-2
5.	1	Inner Cam Bearing Puller	1279-1
6.	1	Instruction Sheet	1279-IS

* Refer to H-D[®] Service Manual for removal of cams and tappets, Use JIMS[®] tool No. 1283 Cam Chain Unloader tool and No. 1285 Cam / Crank Locker tool.

(Note: Read all instructions before performing work) WARNING: Always wear eye protection and always disconnect the negative cable on the battery.

- 1. Disassemble tool by removing nut, brass washer, sleeve, and inner pin. This will leave just the remover portion of tool (the piece with the four grooves), we call it the puller.
- 2. Push the puller through the cam bearing (groove end first). You can tap end of puller with a soft hammer until the puller is completely through bearing.
- 3. Now install body with puller bore towards bearing, next apply a little oil to washer face and the thread of the nut.
- 4. Snug up nut, apply a little oil to the pin and slip pin through center until flush with puller end.
- 5. With your 1 1/8" wrench turn nut clockwise until bearing is free of case (you may need to hold puller with a 5/8" wrench to keep it from turning. (Caution: Do not turn tool with your 5/8" wrench, you will damage tool.)
- 6. Install new JIMS[®] Bearing No.9198 with tool No.1278.

CAUTION: Wear safety glasses. Excessive force may damage parts and tool. See JIMS® catalog for over 200 other top quality professional tools. The last tools you will ever need to buy.

"From the Track... To the Street!"

555 Dawson Drive, Camarillo, CA 93012 Phone 805-482-6913 • Fax 805-482-7422