



## Instruction Sheet For Tool No.2388

### TOOL DRIVER SPACER

Use with driver tools No.33071-73, 94547-80a, 94547-80b

Use with JIMS® Tool handle No. 33416-80



1. Refer to H.D. Service Manual for specifications.
2. Place half of tool into bearing cup at a time.
3. With both halves inserted into the bearing race, install tool driver spacer in center of tool.
4. Install handle into the hole in driver spacer, press out the race.

**CAUTION:** Wear safety glasses. Excessive force may damage parts! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

***"From the Track... To the Street!"***

555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422



## Instruction Sheet For Tool No.2388

### TOOL DRIVER SPACER

Use with driver tools No.33071-73, 94547-80a, 94547-80b

Use with JIMS® Tool handle No. 33416-80



1. Refer to H.D. Service Manual for specifications.
2. Place half of tool into bearing cup at a time.
3. With both halves inserted into the bearing race, install tool driver spacer in center of tool.
4. Install handle into the hole in driver spacer, press out the race.

**CAUTION:** Wear safety glasses. Excessive force may damage parts! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

***"From the Track... To the Street!"***

555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422