



Instruction Sheet For Tool No.2357

ROCKER ARM BUSHING INSTALLATION TOOL

Use to install rocker arm bushings in rocker arms with or without a press.
Use on Big Twins 1966-present
use on Sportsters 1957-present



1. Refer to H.D.® Service Manual for removal of rocker arms.
2. Remove old rocker bushing using JIMS® Tool #95760-57.
3. Before installing bushings, refer to H.D.® Service Manual to correctly align oil holes.
4. Apply a press fit lube, like JIMS® #2124, on bushings. Position rocker arm over stud on tool base with tool pilots and bushings in place. Install press bushing tube over stud. Recheck oil hole position and press on tube until both bushings bottom out. At this point the bushings will be set at the right depth. NOTE: A nut is provided if no press is available.
5. Ream bushings using JIMS® Tool #94804-57

PARTS AVAILABLE SEPARATELY

NO.	PART NO.	QTY.	DESCRIPTION
1	2357-1	1	BASE, PRESS BUSHING
2	2357-2	2	PILOT, PRESS BUSHING
3	2357-3	1	TUBE, PRESS BUSHING
4	2360	1	STUD, 3/8 - 16 X 6.0 LG.
5	2035	1	NUT, 3/8 - 16
6	2031	1	WASHER

CAUTION: Wear safety glasses. Excessive force may damage parts! See JIMS® catalog for over 100 other top quality professional tools. The last tools you will ever need to buy.

"From the Track... To the Street!"