



Instruction Sheet For #2245



Clutch Lock plate Use on big twin 1941-84

Use to lock clutch shell to clutch hub on all Big Twins, 1941-84.

CAUTION: Remove ground cable from battery.

1. Refer to H.D.® Service Manual for removal of primary cover.
2. Disassemble clutch according to H.D.® Service Manual.
3. Insert clutch lock plate between clutch hub and shell. Bend ears of lock washer away from hub nut, use JIMS® tool #2316 Primary Locking Bar, to keep clutch housing from turning, remove clutch hub nut. NOTE: Clutch hub nut has left hand threads.

CAUTION: Wear safety glasses. Excessive force may damage parts!
See JIMS® catalog for over 100 other top quality professional tools.
The last tools you will ever need to buy.

"From the Track... To the Street!"

555 Dawson Drive, Camarillo, CA 93012 • Phone 805-482-6913 • Fax 805-482-7422